

CUFF ENTRY FITTINGS



Ph: 707.523.2050, Fx: 707.523.2050, sales@westernfg.com, www.westernfg.com

SINGLE WALL CUFFS

DESCRIPTION	SET	LIST	INNER CUFF ONLY	LIST	INNER BOOT ONLY	LIST	SPLIT REPAIR 1-BOOT	LIST
SW Cuff- Electrical	SWCUFF1.4-V	\$ 230	CUFF1.4-IP	\$ 115	CUFF1.4-IB-V	\$ 110	CUFF1.4-IB-SPL-V	\$ 117
SW Cuff- 1.5" Co-Flex	SWCUFF2.0-V	\$ 230	CUFF2.0-IP	\$ 115	CUFF2.0-IB-V	\$ 110	CUFF2.0-IB-SPL-V	\$ 117
SW Cuff- 2" FRP	SWCUFF2.4-V	\$ 230	CUFF2.4-IP	\$ 115	CUFF2.4-IB-V	\$ 110	CUFF2.4-IB-SPL-V	\$ 117
SW Cuff- 2" Co-Flex	SWCUFF2.5-V	\$ 230	CUFF2.5-IP	\$ 115	CUFF2.5-IB-V	\$ 110	CUFF2.5-IB-SPL-V	\$ 117
SW Cuff- 2" LCX	SWCUFF2.7-V	\$ 230	CUFF2.7-IP	\$ 115	CUFF2.7-IB-V	\$ 110	CUFF2.7-IB-SPL-V	\$ 117
SW Cuff- 3" FRP	SWCUFF3.6-V	\$ 230	CUFF3.6-IP	\$ 115	CUFF3.6-IB-V	\$ 110	CUFF3.6-IB-SPL-V	\$ 117
SW Cuff- 3" LCX	SWCUFF3.8-V	\$ 230	CUFF3.8-IP	\$ 115	CUFF3.8-IB-V	\$ 110	CUFF3.8-IB-SPL-V	\$ 117
SW Cuff- 4" FRP	SWCUFF4.5-V	\$ 230	CUFF4.5-IP	\$ 115	CUFF4.5-IB-V	\$ 110	CUFF4.5-IB-SPL-V	\$ 117

DOUBLE WALL CUFFS

DESCRIPTION	SET	LIST	OUTER CUFF ONLY	LIST	OUTER BOOT ONLY	LIST	SPLIT REPAIR 2-BOOTS	LIST
DW Cuff- Electrical	DWCUFF1.4-V	\$ 307	CUFF1.4-OP	\$ 115	CUFF1.4-OB-V	\$ 130	CUFF1.4B-SPL-V	\$ 247
DW Cuff- 1.5" Co-Flex	DWCUFF2.0-V	\$ 307	CUFF2.0-OP	\$ 115	CUFF2.0-OB-V	\$ 130	CUFF2.0B-SPL-V	\$ 247
DW Cuff- 2" FRP	DWCUFF2.4-V	\$ 307	CUFF2.4-OP	\$ 115	CUFF2.4-OB-V	\$ 130	CUFF2.4B-SPL-V	\$ 247
DW Cuff- 2" Co-Flex	DWCUFF2.5-V	\$ 307	CUFF2.5-OP	\$ 115	CUFF2.5-OB-V	\$ 130	CUFF2.5B-SPL-V	\$ 247
DW Cuff- 2" LCX	DWCUFF2.7-V	\$ 307	CUFF2.7-OP	\$ 115	CUFF2.7-OB-V	\$ 130	CUFF2.7B-SPL-V	\$ 247
DW Cuff- 3" FRP	DWCUFF3.6-V	\$ 307	CUFF3.6-OP	\$ 115	CUFF3.6-OB-V	\$ 130	CUFF3.6B-SPL-V	\$ 247
DW Cuff- 3" LCX	DWCUFF3.8-V	\$ 307	CUFF3.8-OP	\$ 115	CUFF3.8-OB-V	\$ 130	CUFF3.8B-SPL-V	\$ 247
DW Cuff- 4" FRP	DWCUFF4.5-V	\$ 307	CUFF4.5-OP	\$ 115	CUFF4.5-OB-V	\$ 130	CUFF4.5B-SPL-V	\$ 247

CUFF ACCESSORIES & BONDERS

DESCRIPTION	PART NUMBER	LIST
Sump Bond Kit- Single (1-gal Resin, 1-gal putty, 4 oz MEKP, 3 oz FRP Mat)	AC8007	\$ 150
Sump Bond Kit- Bulk (3-gal Resin, 1-gal putty, 8 oz MEKP, 3 oz FRP Mat)	AC8004	\$ 410
Boot Bonder- Methyl Methacrylate, Large Tube (490 ml)	DWAC600	\$ 140
Installation Gun- for DWAC600	DWAC601	\$ 500
Mixing Tips (5-pk)- foe DWAC600	DWAC602-5	\$ 32
Boot Bonder- Methyl Methacrylate, Mini Tube (50 ml)	DWAC600-SM	\$ 50
Installation Gun- for DWAC600-SM	DWAC601-SM	\$ 120
Mixing Tips (5-pk)- foe DWAC600-SM	DWAC602-5-SM	\$ 32

SUMP RETROFITS

RETROFIT KITS & OPTIONS

DESCRIPTION	PART NUMBER	LIST
Retrofit Kit- 32" Twist-Seal Lid	TA3005-TS32	\$ 719
Retrofit Kit- 37" Twist-Seal Lid	TA3005-TS37	\$ 719
Retrofit Kit- Type A Lid	TA3005-A	\$ 719
Retrofit Kit- Type B Lid	TA3005-B	\$ 719
Type A Kit for Riser Reducer- Includes Gasket, Caulking & Mounting Hardware	TA9980	\$ 369
Type B Kit for Riser Reducer- Includes Gasket, Caulking & Mounting Hardware	TA9985	\$ 185
Sump Bond Kit- Single (1-gal Resin, 1-gal putty, 4 oz MEKP, 3 oz FRP Mat)	AC8007	\$ 150
Sump Bond Kit- Bulk (3-gal Resin, 1-gal putty, 8 oz MEKP, 3 oz FRP Mat)	AC8004	\$ 410