

## **INSTALLATION INSTRUCTIONS**

### **Transition Containment Frame**

Please read all instructions completely prior to installation. These instructions do not supersede local laws and regulations. Always comply with local requirements.

- 1) Inspect Containment Frame upon receipt for any shipment damage.
- 2) Ensure that the Containment Frame is properly sized for the existing dispenser containment and the new dispenser.
- 3) Remove existing dispenser, splashguard and dispenser anchor bolts.
- 4) Install new anchor bolts as per manufacturer's installation instructions.
- 5) Ensure that the bolt pattern for the new splashguard is the same as the new dispenser. Trace footprint of new splashguard to concrete.
- 6) Clean all surfaces to be sealed as per adhesive/sealant instructions.
- 7) Apply Western Fiberglass approved sealant between concrete and new splashguard. Apply minimum 1/2" bead. It is strongly recommended that the seam between the existing containment and existing concrete be resealed.
- 8) Install new Fiberglass UDC Transition Containment Frame.
- 9) Test containment frame:
  - a. Pour water at all areas inside of new splashguard and ensure water is directed toward existing containment sump.
  - b. Inspect outside of new splashguard for any signs of liquid and/or moisture.
  - c. If moisture is found outside the new splashguard, identify leak and repair.
  - d. Allow to cure overnight and re-test.
  - e. Remove all water from the containment sump.
- 10) Re-install dispenser.